

SAFETY RETROFIT

GERBER® GATOR® COMBO AXE

Hammering or chopping with the axe without first removing the knife from the axe handle can create a force upon impact which may cause the knife to come out of the handle and stick upright, and on the next down stroke the knife can pose a laceration hazard to the user.

This retrofit applies only to the knife-in-handle Combo Axe, which looks like this:



This retrofit does not apply to the saw-in-handle Combo Axe II, which looks like this:



If you have a knife-in-handle Combo Axe, always remove the knife from the axe handle before using the axe, and call Gerber to receive your free Handle Cap, instructions for installing the Handle Cap, and a warning sticker. Once installed, the Handle Cap will keep the knife securely in the axe handle during transport and storage. Call Gerber toll free at:

(877) 314-9130

between 9 a.m. and 5 p.m. Pacific time, Monday through Friday
or visit Gerber's website:

www.gerbergear.com

In cooperation with the U.S. Consumer Product Safety Commission

Post until July 31, 2011